

# ANALOG WAY LIVECORE™

## Module: GPIO

## AMX NETLINX

Date: **January 03, 2017**  
Driver version: **V3.01**  
Compatible with: **LiveCore™ Firmware v04.00.x or above**

### GENERAL

This is an optional module for controlling LiveCore™ series processors. It allows control of GPI and GPO available on:

- a LiveCore™ processor (master device)
- a LiveCore™ processor (master device) and a LiveCore™ Expansion module (slave device)
- a LiveCore™ processor (master device) and a compatible LiveCore™ processor linked together (slave device)

Important: One single GPIO module must be included even if you intend to control GPIO of a slave device.

## IMPLEMENTATION

To interface this module in an AMX program, the programmer must perform the following tasks:

- Edit the file LiveCore\_User\_Definitions.axi: If the GPIO module is used in the main program then you must assign the value 1 to the variable LiveCore\_GPIO\_Usage. If this is not the case, the value of this variable must remain at 0.
- Include the LiveCore\_GPIO module in the main program and adjust specific module parameters (see example program available with this package).

## COMMANDS

### Command Control

None

### Channels

The channels supported by the GPIO module are listed below.

| Code channel | Description  |
|--------------|--|
| 11..18       | Include/exclude a screen in/from the list of screens that will execute a TAKE action when the GPI is activated on the Master LiveCore™ device (channel 11 for screen 1, channel 12 for screen 2, ...)  |
| 31..35       | Activate/deactivate a GPO on the Master LiveCore™ device (channel 31 for GPO 1, channel 32 for GPO 2, ...)   |
| 111..118     | Include/exclude a screen in/from the list of screens that will execute a TAKE action when the GPI is activated on the Slave LiveCore™ device (channel 111 for screen 1, channel 112 for screen 2, ...) |
| 136..140     | Activate/deactivate a GPO on the Slave LiveCore™ device (channel 31 for GPO 1, channel 32 for GPO 2, ...)  |
| 255          | Module initialization (automatically performed after being connected)  |

## Levels

The levels supported by the GPIO module are listed below.

| Code level | Description  |
|------------|--|
| 31..35     | Mode selection for a GPO on the Master LiveCore™ device (channel 31 for GPO 1, channel 32 for GPO 2, ...)<br><br>Values :<br>- 0 : free GPO mode<br>- 1 : Tally GPO mode (GPO changes during take event)<br>- 2 : Tally GPO mode (GPO changes after take event)  |
| 136..140   | Mode selection for a GPO on the Slave LiveCore™ device (channel 136 for GPO 1, channel 137 for GPO 2, ...)<br><br>Values :<br>- 0 : free GPO mode<br>- 1 : Tally GPO mode (GPO changes during take event)<br>- 2 : Tally GPO mode (GPO changes after take event) |

## FEEDBACKS

## Channels

The channels supported by the GPIO module are listed below.

| Code channel | Description  |
|--------------|--|
| 1            | GPI availability on the Master LiveCore™ device  |
| 2            | GPI status on the Master LiveCore™ device  |
| 21..25       | GPO availability on the Master LiveCore™ device (channel 21 for GPO 1, channel 22 for GPO 2, ...)  |
| 31..35       | GPO status on the Master LiveCore™ device (channel 31 for GPO 1, channel 32 for GPO 2, ...)        |
| 101          | GPI availability on the Slave LiveCore™ device   |
| 102          | GPI status on the Slave LiveCore™ device   |
| 123..130     | GPO availability on the Slave LiveCore™ device (channel 123 for GPO 1, channel 124 for GPO 2, ...) |
| 136..140     | GPO status on the Master Slave device (channel 136 for GPO 1, channel 137 for GPO 2, ...)          |
| 255          | Module initialization status   |

## **Levels**

The levels supported by the GPIO module are listed below.

| Code level | Description   |
|------------|---|
| 31..35     | GPO mode on the Master LiveCore™ device (level 31 for GPO 1, level 32 for GPO 2, ...)<br><br>Values : <ul style="list-style-type: none"><li>- 0 : free GPO mode</li><li>- 1 : Tally GPO mode (GPO changes during take event)</li><li>- 2 : Tally GPO mode (GPO changes after take event)</li></ul>  |
| 136..140   | GPO mode on the Slave LiveCore™ device (level 136 for GPO 1, level 137 for GPO 2, ...)<br><br>Values : <ul style="list-style-type: none"><li>- 0 : free GPO mode</li><li>- 1 : Tally GPO mode (GPO changes during take event)</li><li>- 2 : Tally GPO mode (GPO changes after take event)</li></ul> |