

ANALOG WAY LIVEPREMIER™

Module: MASTER_PRESETS

Crestron 3-series & 4-series

Date: **June 30th 2021**
Driver version: **V2.1.0**
Compatible with: **LivePremier™ Firmware V2.0.231 or above**

GENERAL

This module reads LivePremier™ master presets status and provides its related controls.

Control

Parameters

MasterPresetOffset	Param	The offset where master presets will start. The first preset will be (MasterPresetOffset+1)
--------------------	-------	---

General

Master_RefreshInfos	Digital_in	Pulse this signal to force information retrieval. Most of the time this signal is never use
---------------------	------------	---

Recall

Master_Recalling_FB	Digital_out	Equals 1 when a master preset is being loaded
Master_PreviewPreset_Cmd[X]	Analog_in	Index of the master preset to load to the preview destination
Master_ProgramPreset_Cmd[X]	Analog_in	Index of the master preset to load to the program destination
Master_PreviewPreset_FB[X]	Analog_out	Index of the latest master preset loaded to the preview destination
Master_ProgramPreset_FB[X]	Analog_out	Index of the latest master preset loaded to the program destination

Availability

Master_Valid_FB[X]	Digital_Out	Equals to 1 when a master preset exists and is valid, 0 otherwise
--------------------	-------------	---

Label

Master_Label_FB[X]	String_Out	The master preset label
--------------------	------------	-------------------------