

# ANALOG WAY VERTIGE™

## Module: GENERAL

### AMX NETLINX (NIxxx or NXxxx)

Date: **November 4, 2016**  
Driver version: **V1.00**  
Compatible with: **Vertige™ Firmware v03.03.00 or above**

## INTRODUCTION

This module is the core module, required to control Vertige™ console. Even if you use only one optional module, the GENERAL module must be included in the project. This module mainly provides Vertige™ console information feedback as well as some remote control functions.

## IMPLEMENTATION

To interface this module in an AMX program, the programmer must perform the following tasks:

- Include the Vertige\_General module in the main program and adjust specific module parameters (see example program available with this package).

## COMMANDS

### Command Control

None

### Channels

The channels supported by the GENERAL module are listed below.

Channel code	Description
1	Initiate IP connection
2	Stop IP connection
251	Reboot the Vertige™ processor
254	Module initialization (automatically performed after being connected). When done, any other modules included and declared in the project will be initialized
255	Global update (all modules)

## FEEDBACKS

### Channels

The channels supported by the GENERAL module are listed below.

Channel code	Description
253	IP connection status
255	Module initialization status

### Texts

The texts supported by the GENERAL module are listed below.

Address code	Description
1	Vertige™ console type
2	Vertige™ console version
3	Vertige™ console Updater version
4	Vertige™ console Firmware version
6	Vertige™ TCP/IP connection status
21	End user messages